

Microcontroller Engine Governor

Griffin White - Spring 2023 Revised 1-18-2023





Component Descriptions and Functions Flywheel / The flywheel assembly rotates at a constant speed. It is **Trigger Wheel** spun by the gasoline engine. The electrical load places more / less strain on the Variable AC generator, requiring the throttle to increase / decrease **Electrical Load** accordingly. The engine spins the flywheel. Its speed is controlled **Engine** via the throttle valve. The throttle valve regulates the amount of fuel / air **Throttle** provided to the engine, thereby regulating its speed. It Valve is controlled by the stepper motor. The stepper motor controls the position of the throttle Stepper valve, thereby controlling the speed of the engine. It is Motor controlled by the Arduino.

Hall-Effect

Sensor

Arduino

The hall-effect sensor produces a signal each time that

a ferrous tooth passes by it. Using this signal, we can

measure the RPM of the flywheel.

The Arduino microcontroller monitors the flywheel RPM

and adjusts the stepper motor as needed.

